



Instructions for QDS Combo Wipes

May 2024

Instructions:

1. Remove the roll
2. Add 500ml DI water to the canister
3. Reinsert the Roll of fabric
4. Shake the canister to distribute the water through the wipes
4. Turn canister upside down and leave for 2 minutes
5. Turn the canister right side up and pull the wipes through top

NOTE 1: Shelf Life: 10 years if no water added; – 60 days after water has been added

NOTE 2: If wipes are dried out following adding water, add DI water to re-moisten.

***RT Technologies Inc.
2472 Jett Ferry Rd, STE 400, PMB 401
Dunwoody, GA 30338***

***Telephone: 770-332-0092
Fax: 770-332-0092
Email: contact@rtlasersafety.com
Web: www.rtlasersafety.com***